

**DeckWright Anti-Slip Inserts**

# Fitting Instructions



*QUICK & EASY TO INSTALL IN JUST 4 SIMPLE STEPS...*



Ensure inserts are <math>< 18^{\circ}\text{C}</math> and deckboard is clean, dry and free from dust or debris.



Apply 3mm bead of adhesive to the deckboard groove where the insert is to be placed.



Trim to desired length, place into groove and apply pressure.



For best results, allow to dry for a minimum of 3 hours.

If used for a commercial project in high traffic areas, then additional fixing maybe required.